



## Part List

No.	name	qty	unit
22HC-0101	tank	1	pcs
21HC-0201	directional wheel	2	pcs
21HC-0202	snap ring	2	pcs
21HC-0301	universal wheel	2	pcs
21HC-0302	nut	2	pcs
21HC-0501	level pipe	0.4	m
21HC-0502	elbow connector	2	pcs
21HC-0503	level pipe protector	1	pcs
21HC-0504	hexagonal screw	2	pcs
21HC-1801	oil drain hose	2	m
21HC-1802	oil drain hook	1	pcs
21HC-1902	screw	2	pcs
21HC-2003	screw	2	pcs
21HC-2101	fixing seat	1	pcs
21HC-2102	seal ring	2	pcs
21HC-2105	lift pole	1	pcs
21HC-2106	ball valve	1	pcs
22HC-2501	oil tray	1	pcs
21HC-2502	strainer	1	pcs
21HC-2704	connector	1	pcs
21HC-2801	handrail	1	pcs
21HC-3802	gasket	2	pcs
21HC-3901	plug	2	pcs
32HC-0303	gasket	4	pcs
32HC-0304	thread rod	2	pcs
32HC-0401	cast-iron bend	3	pcs
32HC-0402	butterfly valve	1	pcs
32HC-0601	safe valve	1	pcs
32HC-0701	pressure gauge	1	pcs
32HC-0801	wind nozzle	2	pcs
32HC-0802	elbow connector	2	pcs
32HC-0803	mini ball valve	1	pcs
32HC-1901	tool box	1	pcs
32HC-1903	nut	2	pcs
32HC-2103	seal ring	2	pcs
32HC-2104	brake sleeve	1	pcs
32HC-2107	knob	1	pcs

32HC-2703	handle sleeve	2	pcs
22HC-4303	locating sleeve	1	pcs
22HC-4304	hex socket set screw	1	pcs
22HC-4307	lift	1	pcs